Mandis shop

REMCON1682

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| | On/1/W1/W2/W | | Power | | |
| | Off/0 | | Shift + Power | | |
| | Time | | Sleep / Timer | | |
| | Turn | | Back / Return | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

https://alle-fernbedienungen.de/en/UNKNOWN/1065221-93883-replacement-remote-control-for-UNKNOWN-REMCON1682.html